

ECHOFLEX & ECHOVELOUR

CARE & CLEANING GUIDE



STAINS AND RECOMMENDED TREATMENT

Woven Image's EchoFlex and EchoVelour ranges are manufactured with the highest quality materials and requires minimal up keep to maintain its high quality finish.

Before starting any recommended cleaning method always spot check on a concealed section to ensure it will not impact the adhesives or product. Treat spills and stains as soon as possible by using a damp cloth using the cleaning guide below.

STAIN	RECOMMENDED TREATMENTS
Dust, dirt	<ul style="list-style-type: none">• A light vacuum using an upholstery attachment on low suction.• Do not use vacuum attachment with a rotary brush.• Brushing may damage the nap or character of the fabric.
Chewing gum, chocolate, cooking oils, crayon/markers, grease, oil, mud	<ul style="list-style-type: none">• Remove surplus with a knife edge or appropriate instrument.• Softly sponge with household dry cleaning fluid and blot dry.• Apply subtly to not impact the adhesive within the product.
Drinks. paint	<ul style="list-style-type: none">• Blot the excess moisture with a dry clean cloth.• Softly sponge with household dry cleaning fluid and blot dry.• Apply subtly to not impact the adhesive within the product.
Pen, mildew	<ul style="list-style-type: none">• Softly sponge with household dry cleaning fluid and blot dry.• Apply subtly to not impact the adhesive within the product.

Note:

Woven Image recommends consulting with a professional cleaner if you require any further assistance on stubborn stains.